



Release Detection

Has a release occurred?

During release detection, sampling data are collected near known waste deposits or ecological receptors to determine whether a statistically significant contaminant release into environmental media has occurred. Given that geospatial methods require substantial preexisting data, they are best applied when ongoing monitoring provides the necessary data set (such as detection monitoring at a RCRA waste disposal unit or a landfill). Geospatial methods are also best applied where the contaminants are detected above background levels, such as with some metals, or where the detections of organic contaminants are observed but the concentrations are not over some action level. Information about managing [nondetect data](#) is included in the GSMC-1 document.

During release detection, geospatial methods can help to optimize the following:

- identifying additional monitoring locations
- determining background values (see [GSMC-1](#) for more information about background conditions)
- determining the horizontal and vertical extent sufficient to make appropriate initial decision
- assessing the number of monitoring locations and frequency of monitoring

Optimization through geospatial methods is sometimes limited by the lack of data at this stage in the life cycle.

Figure 2 provides an overview of the role of geospatial methods in this stage of the project life cycle. Each general topic and specific question is linked to a more detailed discussion.

Release Detection

Method Category

Other Methods

Simple Methods

More Complex Methods

Advanced Methods

Plume Detection and Estimation

Do various detected concentrations represent an actual plume?

Methods to answer this question

Inverse distance weighting
natural neighbor

Local spatial regression

Kriging (including co-kriging)

Trend Maps

Are there significantly different concentration trends in different parts of the site?

Methods to answer this question

Temporal trend estimation

Local spatial regression

Kriging
(including indicator kriging)

Estimating Average Concentrations

What are the average concentrations for different chemicals and how may they be changing over time as an indication of a release?

Methods to answer this question

Declustering using
voronoi polygons

Block kriging

Hot Spot Detection

Are there hot spots of interest at the site?

Methods to answer this question

Traditional statistics

Variograms

Figure 2. Release detection overview.

Release Detection: Plume Detection and Estimation

Do various detected concentrations represent an actual plume?

▼ [Read more](#)

Geospatial techniques offer spatial mapping of measurement data; they serve as an alternative to professional judgment or hand contouring when creating site maps. Mapping can help to locate areas of a site where a plume may be developing and assists in qualitatively determining whether a plume is present. For more information, see the discussion on using geospatial results to determine [plume intensity and extent](#).

Geospatial Methods:

1. [Simple geospatial methods](#) (for example, inverse distance weighting, natural neighbor interpolation) can also provide a map and, in some cases, a measure of a goodness of fit.
2. [More complex methods](#) (for example, [local spatial regression](#)) can be used to interpolate the data over time and space or easily incorporate other predictor variables into the analysis to improve the interpolation.
3. [Kriging](#) (including [co-kriging](#), for example, with an indicator compound) can map the plume and assess uncertainty in the interpolations between data points.

Release Detection: Trend Maps

Are there significantly different concentration trends in different parts of the site?

▼[Read more](#)

Trend maps are an efficient way to look for possible contaminant releases. Instead of mapping the site and tracking the map over a series of time points, the slope direction and magnitude are estimated at each sampling location and then plotted on a site map, which can be contoured. A trend map provides a spatial overview of which areas of the site are increasing or projected to increase in concentration, as well as how quickly the concentrations are changing. Further discussion on how to use the trend map is provided in [remediation trend map](#) section. For more information on using geospatial results to understand trends, see [Trend Maps](#).

Geospatial Methods:

1. Temporal trend estimation (for example, linear regression, Mann-Kendall, Theil-Sen) can be combined with plotting of the magnitude and direction of the trends at specific locations on a map. The [GSMC-1](#) document ([ITRC 2013](#)) includes more information on trend estimation methods.
2. More complex methods (for example, [local spatial regression](#)) can be used to interpolate the data over both space and time to provide a series of plume maps at different times.
3. Kriging, including indicator kriging, can be used to map the likely distribution of the determined trend. The statistical confidence in the trend (positive values for increasing trends and negative values for a decreasing trend) can be kriged, or indicator kriging can be used to evaluate certainty of trends by assigning a one to an increasing trend and a zero to the opposite trend.

Release Detection: Estimating Average Concentrations

What are the average concentrations for different chemicals and how may they be changing over time as an indication of a release?

▼[Read more](#)

In order to assess whether a plume might be emerging, the average site concentration can be estimated and periodically tracked over time. See the further discussion of using geospatial results in estimating quantities and average concentrations.

Geospatial Methods:

1. Averages of spatial data can be affected by spatial correlation (nonindependent data). Declustering using a grid or [Voronoi polygons](#) can be applied to weight spatially clustered data. This practice results in a more accurate estimate of the population mean.
2. [Block kriging](#) can also be used to account for spatial correlation in assessing averages over a block or study area.

Release Detection: Hot Spot Detection

Are there hot spots of interest at the site?

▼[Read more](#)

During release detection, it may be necessary to identify areas of elevated concentration (hot spots) or to evaluate the likelihood that areas of the site exceed regulatory limits. Hot spots can be found by sampling on a systematic grid with [traditional statistics](#) or through use of row- and column-aligned [incremental sampling methods](#) (ISM). Geospatial analysis of these data may help to identify hot spots. Geospatial methods may allow better incorporation of hot spot concentrations in characterizing site conditions. Examples include ordnance detection with geophysical data, or characterization of a large area with random storage or disposal of hazardous waste. Note that geospatial methods require some existing data to guide the collection of additional data. Choosing efficient and effective sample spacing (in space or time) for any medium can help to optimize a sampling program for detection of a hot spot. For more information, see the discussion of using geospatial results in [hot spot detection](#).

Geospatial Methods:

1. [Variograms](#) can help select optimal grid spacing based on the degree of spatial correlation for detecting hotspots of a given size. The variograms can indicate the distances at which the sampling locations can be spaced without yielding too much duplicative information. Hot spots usually have high variability over short distances, so closer spacing is appropriate.

